

Installation Instruction Opel 1.9 CDTi 150hp

▶ 1. Preparations

Switch the ignition off.
Wait, until all electric power consumers are switched off.
Remove the engine cover (see ill.2)

▶ 2. Cable harness installation

Localise the 4 injectors with the 2-pole connections (see ill.3/4). Connect the adaptor cable of the PDI system with the original plugs.

Connect the power supply at the vehicle battery (see ill.2).
Move the cable if possibly splash water protected and avoid attaching in hot engine parts.

Put the PDI module on the Sub-D connection (see ill.4)

▶ 3. Settings - fine adjustment

The system is preset. Normally you will not need to adjust the module.
If you want to increase or reduce the power performance, you will only need to place the jumper to the left (increased efficiency) or to the right (reduced power performance). Please contact the manufacturer, before changing the jumper settings.

Now fit the engine cover back on. The vehicle is ready for a test drive.

To restore the standard state, you must remove only the PDI module. The adapter cable can remain connected.



You still have questions or you are not quite sure?
Contact us, a technician will gladly help you!

ill.4 installation principle

